






## TURNING PAGER ON



Press and hold  for 2 seconds.


## TURNING PAGER OFF


1. From Main Menu, press  once for Function Menu
2. Press  five times to select TURN OFF function.
3. Press . "TURN OFF?" is displayed. Press  again to confirm or  to cancel.

## FUNCTION MENU

Press  to enter the Function Menu from Main Menu

Press  /  to move to the previous/next Function Menu icon.


Press  to enter the current selected function sub-menu.

Press  to cancel and return to the Main Menu.










## RECEIVING/READING MESSAGES

Press  to read the message













## DELETING A MESSAGE/ALL MESSAGES

- A message is defined as read once the first page of the message has been read. Previewing a message is not considered as reading a message.
- Locking a message prevents it from being accidentally deleted or overwritten by new messages. You can lock up to 15 messages.
- You can enter Inbox Message Function menu by pressing  when you are reading the message. The operation is the same as the Inbox Folder Function Menu except there is no "DELETE ALL".
- Please note. Locked messages cannot be deleted. Additionally, unread messages cannot be deleted by using "DELETE ALL".











## SETTING THE TIME & DATE

- Press  once. "SET ALERT" is displayed. Press the  button once to "SET TIME" then press  and a 12 hour clock appears.
- To select the 12hr or 24hr clock press  then press  to advance and set the hour of your pager.
- After pressing  to highlight the hour field, use the  to choose the value.
- Repeat the above steps for setting minutes, AM/PM, day, month, and year.
- Press  to confirm settings,  to cancel.



## SETTING THE ALARM

- Press  from Main Menu screen to go to the Function Menu screen, "SET ALERT" will appear. Press  three times to select "SET ALARM" then press  to enter and a flashing  appears.
- Press  to turn the alarm ON  or OFF . Press  to move to the time field.
- Press  to change the hour then press  to move to the next field. Repeat this step for setting minutes, AM/PM, day, month, and year.
- Press  to confirm settings, or  to cancel.
- When the Alarm is active an Alarm icon is displayed in the Status Bar.








## SETTING PRIVATE TIME

- From the Main Menu, press  once to go to the Function Menu screen, "SET ALERT" will appear. Press  twice to select "PRIVATE TIME", then press  to enter. A flashing clock appears.
  - Press  to activate or deactivate the Private Time function. \*
  - Press  to go to the "START" field, press  to set the starting time. Then press  to go to the "END" field, press  to set the ending time.
  - Press  to confirm settings, or  to cancel.
- \* A dot at the left of the Status Icon Display indicate that the function is active.


## BACKLIGHT

- Press and hold  for two seconds to turn ON the backlight manually
- Press and hold  for two second to turn OFF the backlight manually







## SET ZOOM

- Press  once from Main Menu screen to enter the Function Menu screen and "SET ALERT" will appear. Press the  button four times to select "PAGER CONTROL", then press the  button and scroll the button three time and "ZOOM" appears. Press  to enter the Set Zoom menu.
- Press  to switch ZOOM ON of OFF.
- Press  to confirm your settings, or  to cancel.

## QUICK ACCESS TO VIBRATE MODE

- Press and hold  for two seconds to access vibrate mode
- Repeat the process to return to previously active alert mode.

## SETTING ALERTS

- Press  to enter the Function Menu screen from the Main Menu screen
- Press  to enter alert mode sub function. The current alert setting will blink
- Press  /  to move to different alert modes and hear a sample from vibrate, sleep, vibra-call, chirp, continuous alert and pleasing alerts 1-8
- Press  to confirm your selection, or  to cancel